



RACE DIRECTION ROOM

DC1 Tracking Message

Elite stream Messages

DC2

RJ45

ELITEV3 MASTER
Tracking Broadcast
Remote display

ELITEV3 SLAVE
OLED
Live timing

TCDCOM

MASTER DECODER WITH SPEAKERS

NETWORK & HDD

USB

Ethernet

Video composite signal

ELITEV3 MR MASTER BACKUP

PHOTO FINISH

SLAVE DECODER

IDVISION

TCDCOM

ELITEV3 ADMIN

PHOTO FINISH CAMERA

PROFESSIONAL TIMING

VIDEO CHANNEL

ITS CHRONO SPEED CIRCUIT INSTALLATION SCHEME

- RS485
- RJ45 Cable
- RCA or BNC Cable
- RG58 or 223 coaxial Cable
- USB to PC/TV Converter